

Fitting instructions:

Maybury Pinfix Numbers:

Tools required:

- drill
- 3.5mm drill bit
- small block of wood
- few sheets of newspaper
- hammer

1. Screw the pins into the rear of the numbers. Then gently press them against the surface of what they will be fixed to, so that the pins make a small mark where they will be located. Be careful to ensure the numbers are correctly aligned (it may help to draw a line in pencil so they sit level).

2. Drill a 3.5mm diameter hole at these points, to a depth of 15mm (mark the drill bit with tape).

3. Using the newspaper to protect the surface of the metal and the block of wood to evenly distribute the force of the hammer, locate the pins (still attached to the numbers) in the pilot holes in the door and gently hammer into position. Please take care not to break the pins when hammering.